



TO FULL SET

Key in your user code and press ENTER (or press  on the 525r remote setting device). The exit tone starts. Leave the premises by the designated exit route.

The exit tone stops after a preset time. The alarm system is then set.




 ZONE NUMBER



TO PART SET

To set your alarm system so that you can move around part of the area normally covered by detectors:

Key in your user code and press OMIT. The panel lights all the zones that will work in part set. Key in the numbers of the zones you want to switch on or off. Press ENTER when you have finished. The exit tone starts. Leave the protected area. The tone stops after a preset time. The system is then set. The panel remembers the zones you selected for part set. The next time you want to part set, enter your user code, press OMIT and then ENTER. The system sets after sounding the exit tone.

(If you have a 525r remote setting device, press . The panel part sets in 3 seconds.)


Note: The installer may have disabled the part set facility. Contact them if you have any difficulty.

IF THE SYSTEM WILL NOT SET


If you are setting or part setting the system, but the panel gives an interrupted tone and zone lights are on, then one or more detectors are being triggered. Check that doors and windows are closed and there is no movement in areas covered by movement detectors.

Try to set the system again. If the fault persists call the installer.

TO SWITCH OFF

Enter by the designated entry route. The entry tone starts. Go to the control panel and key in your four digit user code (or press  on your 525r remote setting device). The system switches off.

Why is the panel beeping? If the panel starts "beeping" once a second after you have switched off using your remote setting device then there has been an alarm while you were out. The lights on the panel indicate the cause of the alarm. Key in your user code again to silence the tone.



Note: To set, part set and unset the system using a 524 Remote Keypad, see the User Guide supplied with the keypad.

AFTER AN ALARM

Fire Alarm: The system gives a fire alarm by sounding a continuous tone from the internal sounder, if you have a smoke detector.

1. Evacuate the premises and call the Fire Brigade. Do not attempt to unset the alarm.
2. When the premises are safe, silence the alarm and reset the system.

Intruder Alarm: The panel gives a warbling tone from its internal sounder, and triggers the external bell and strobe (if you have one).

Tamper Alarm: If the panel gives an internal alarm while on Standby then go to the control panel. The tamper light will be on. Call the installer for service.

To Silence an Alarm

Go to the panel, key in your user code. The panel stops the tone and switches off the external bell/strobe. The lights on the panel indicate the cause of the alarm.

To Reset The System

Press RESET. The panel goes to Standby. If the panel does not go to Standby, call the installer.

Why does the panel beep occasionally? The panel gives five short beeps once a minute to call attention to a fault. The lights on the panel indicate the cause of the alarm: a low battery (either in a detector or in the panel itself), a mains failure, or R.F. trouble. Press Reset to silence the tone and then contact your installer.

TO CHANGE YOUR USER CODE

Your new code can be any four digit code not starting with 0 (zero).

Enter your existing user code and press 2. The first four zones light.

Enter your existing user code again. The zone lights go out as you enter the code. After the last digit the panel gives a double bleep and lights the bottom four zones.

Enter your new user code. The zone lights go out as you enter the new code. The panel gives a double bleep when it accepts the new code.



Check the premise



Note: To change the user code of a 524 Remote Keypad, see the User Guide supplied with the keypad.